

DIRECTIONS FOR INSTALLING THE HKS CARBURETOR HEATER

HKS Part Number 04Y-289

Note: 2 Heaters are required, one for each carburetor. When ordering part number 04Y-289 a quantity of 2 should be ordered.

Step 1:

Remove the M3.5 screw and install the carburetor heater as shown in Figures 1 & 2. Note: The M3.5 screw is a 3.50mm metric screw located next to the carburetor float bowl at the carburetor output manifold flange.

Step 2:

Install the heater in place of the M3.5 screw. Do not grip the ceramic heater sleeve as it could damage the heater.

Step 3:

Repeat steps 1 & 2 for the installation of the second heater element on the second carburetor.

Step 4:

Connect the heaters wires (in parallel) to a switched 12vdc power source capable of providing 30 WATTS of total power to both heaters.

CAUTION:

The white portion of the heater is made of ceramic, it is brittle and can break easily. Use caution when handling this part. Do not grip this part of the heater with pliers or use force on this part when tightening the heater into place.

CAUTION:

Do not supply 12vdc power to the heater until it is attached to the carburetor. Applying power to the heater before it is installed could damage the heater.

Specifications:

P/N: 04Y-289

Power: 12VDC, 15 WATTS (30 WATTS total for both heaters)

Package: 1 per package, 2 required

